

Change M1 assembly.



Fig 2. Clip nail under Vision system cover and pull free





With a pair of pliers hold pin and pull away, as shown in Fig 3 and Fig 4. this is a tight assembly.





The angle part of assembly is closest to helmet. Pin is secured as below by pushing in with Pliers. There is a locating groove on the shaft.

